

## Workshop Manual LT.

### Electrical System.

**April 1985 Edition.**

**Supersedes August 1978 Edition.**

---

The manual is divided into separate booklets which can be ordered individually and allocated on the shop floor as required.

This manual is valid for the LT from the start of production (August 1975).

It describes all operations which require special instructions to ensure satisfactory work.

#### Layout of booklets

This booklet has an index according to repair groups to make it easy to find the information required.

Where practical, each description of an operation is preceded by an exploded view which also contains all the main repair instructions. This is supplemented, where necessary, by illustrations – which are referred to in the exploded view – giving details of the fitting positions of parts or showing special tools in use. If a definite sequence has to be followed when dismantling and assembling a component, the exploded view is followed by a description of the main steps of the work sequence. Any adjustments required are also explained.

#### Workshop Bulletins

The workshop bulletins allocated to this booklet should be filed at the back of the booklet. To remind you that bulletins have been published, the manual pages should be marked by hand with the bulletin number as explained in the bulletin heading.

#### Fault finding

The basis for fault finding is the current flow diagram. Further information is given in

- this manual
- "Fault Finding with V.A.G 1466" booklet
- "Fault Finding" binder

Instructions on the elimination of current defects are given in the "Service Handbook".

**Technical information should always be made available to all foremen and mechanics because compliance with the instructions given is essential to ensure vehicle roadworthiness and safety.**

In addition, the normal safety precautions to be observed when working on motor vehicles are also applicable.

## INDEX ACCORDING TO REPAIR GROUPS

Repair Group	Title/Contents	Page
<b>27</b>	<b>Starter, current supply</b>	<b>1</b>
	• Checking battery	1
	• Checking voltage under load	1
	• Checking acid level	2
	• Checking specific gravity	2
	• Charging battery	2
	• Quick charging/starting boost	3
	• Battery handling	3
	• Removing and installing battery	3
	• Fault finding programme: battery discharges	3
	• Fault finding programme: starter turns too slowly to start engine	4
	• Fault finding programme: starter does not turn	5
	• Removing and installing starter	7
	• Repairing starter	8
	• Fault finding programme: alternator warning lamp does not go out when speed increases	14
	• Fault finding programme: alternator warning lamp does not come on when ignition is switched on	15
	• Fault finding programme: checking alternator and voltage regulator with V.A.G 1315 A	17
	• Removing and installing alternator	
	– 2.0 litre engine	18
	– 4-Cylinder Diesel	19
	– 6-Cylinder Diesel up to 11.82	20
	– 6-Cylinder Diesel from 12.82	21
	– 6-Cylinder Turbo Diesel	22

Repair Group	Title/Contents	Page
<b>27</b>	• Repairing alternator	
	– 35 A and 55 A	23
	– 45 A and 65 A (2.80 to 7.80)	24
	– 45 A and 65 A (from 8.80)	25
	– 90 A	26
<b>90</b>	<b>Instruments, Radio</b>	<b>32</b>
	• Repairing dash insert	
	– with tachograph (up to 11.82)	32
	– with clock and speedometer (up to 11.82)	33
	– with rev counter and tachograph (from 12.82)	37
	– with speedometer and rev counter (from 12.82)	38
	• Notes on tachograph	43
	• Notes on odometer	43
	• Fault finding programme: Checking fuel gauge and coolant temperature gauge	44
	• Fault finding programme: horn defective	45
<b>92</b>	<b>Windscreen wiper and washer system</b>	<b>48</b>
	• Repairing windscreen wiper system	48
	• Repairing washer system	49
	• Adjusting wiper arms and spray jets (windscreen washer system)	50
	• Adjusting wiper park position	50
	• Repairing headlight washer system	
	– up to 11.82	51
	– from 12.82	52

Repair Group	Title/Contents	Page
<b>92</b>	<ul style="list-style-type: none"> <li>• Removing and installing wiper rubbers</li> <li>• Adjusting jets (head-light washer system)</li> </ul>	53 53
<b>94</b>	<b>Lights, switches</b> <ul style="list-style-type: none"> <li>• Repair steering column switch <ul style="list-style-type: none"> <li>– up to 9.79</li> <li>– from 10.79</li> </ul> </li> <li>• Removing and installing steering column switch</li> <li>• Removing lock cylinder</li> <li>• Repairing headlights</li> <li>• Repairing taillights</li> <li>• Repairing fog lights</li> <li>• Repairing rear fog light</li> </ul>	54 54 55 56 56 57 59 60 60
<b>97</b>	<b>Wiring</b> <ul style="list-style-type: none"> <li>• Removing and installing relay plate with fuse box <ul style="list-style-type: none"> <li>– up to 9.79</li> <li>– from 10.79</li> </ul> </li> </ul>	62 62 64

Repair Group	Title/Contents	Page
	<ul style="list-style-type: none"> <li>• Removing and installing wiring looms</li> <li>• Fitting sequence for earthing straps</li> <li>• Routing of wiring <ul style="list-style-type: none"> <li>– Near battery</li> <li>– Near gearbox, 6 cylinder engine</li> <li>– Near starter 6 cylinder turbo diesel engine</li> <li>– Near starter, 6 cylinder petrol and NA diesel engine</li> <li>– Engine compartment, 6 cylinder engine, NA diesel and turbo diesel</li> <li>– Engine compartment 6-cylinder petrol engine</li> <li>– Rear Pick-up Van</li> </ul> </li> </ul>	66 68 69 70 71 72 73 74 75 76

## CHECKING BATTERY

From Model Year 1982 the batteries are fitted with plugs which can only be removed with a screwdriver.

### Note:

Removal of plugs is only necessary when the acid level is below the "min" mark on battery housing.

- Pierce the plastic skin at the location provided (arrow) with a screwdriver.



- Place screwdriver in slot and turn plug anti-clockwise to stop.




### Note:

The new plugs can still be screwed in by hand as before.

## CHECKING VOLTAGE UNDER LOAD

### – Disconnect battery earthing strap

The voltage under load can be checked with a battery tester – e. g. V.A.G 1498 (Fig.).



The current load and the minimum voltage vary according to capacity of battery and are shown on a sticker on the tester:

Capacity	Current	Minimum voltage
36 Ah–175 A	100 A	10.0 V
45 Ah–220 A	200 A	9.2 V
54 Ah–265 A	200 A	9.4 V
63 Ah–300 A	200 A	9.5 V
63 Ah–380 A	300 A	9.0 V
88 Ah–395 A	300 A	9.5 V
110 Ah–420 A	300 A	9.5 V

If the voltage is below the specified figure when tested under load for 5/10 seconds the battery is either discharged or defective. Check specific gravity of acid.

### Note:

To avoid the risk of explosion, do not check battery when it is gassing.

**Batteries** with a capacity of more than **63 Ah** must not be checked with the battery tester/charger VW 1266 because this tester is only designed for batteries up to approx. 63 Ah.

## Checking acid level

When the acid level is below the "min" mark, add distilled water only.

Batteries in which the acid level is too high will tend to "boil over" when charged heavily (long journeys in daylight). If acid level is too low it will shorten the service life of battery.

## CHECKING SPECIFIC GRAVITY

The specific gravity in conjunction with the voltage measurement (under load) gives accurate information on the state of charge of a battery. The check is done with a hydrometer.

The higher the specific gravity of the siphoned battery acid is the higher the float will rise. The density of the acid can be read off in specific gravity of degrees Baumé on the scale.

The readings must be as follows:

Condition of charge in normal climatic zones	° Baumé	Specific gravity
discharged	16	1.12
half charged	24	1.20
fully charged	32	1.28

Condition of charge in the tropics	° Baumé	Specific gravity
discharged	11	1.08
half charged	18	1.14
fully charged	27	1.23

## CHARGING BATTERY


### Note:

Smoking or the use of naked lights are not allowed in rooms in which batteries are being charged. Precision tools should also not be left in such rooms.

Frozen batteries must be thawed out before being charged.

With the battery charger V.A.G 1471 up to four 12 Volt batteries and also batteries with different capacities (Ah = Ampere hour) and nominal voltages can be charged normally.

- Disconnect battery earth and positive wire from battery.
- Connect battery to charging appliance, positive to positive, negative to negative.



- Switch on the charging current. The charging current depends on the capacity of the battery and it should be about 20% of the capacity. With a 45 Ah battery it should be about 9.0 A.

When the gassing voltage is reached the charging current should not be than 10% of battery capacity.

With a 45 Amp. hour battery it should be approx. 4.5 Amp.

## QUICK CHARGING/STARTING BOOST

Quick charging only is possible with the battery test and charging appliance VW 1266 whereas with the battery starter charger V.A.G 1472 a starting boost can also be given.

## BATTERY HANDLING

Batteries which have not been used for a long period (e.g. in stock vehicles) tend to self-discharge and can also in addition become sulfated. If these batteries are quick charged with normal charging appliances they do not absorb any charging current or appear to be prematurely fully charged as a result of so-called surface charging. They appear to be defective.

Before these batteries are finally classified as defective, they should be checked:

- a – If the specific gravity of the acid in all cells does not deviate by more than **0.02 kg/dm<sup>3</sup>** (e.g. 1.13 to 1.11) from one another, the battery is to be charged. On completion of the charging process the battery is then given a load test. If it is then discovered that specified readings are not obtained, the battery is defective.
- b – If the specific gravity in one or two adjacent cells drops noticeably (e.g. five cells show 1.6 and one cell 1.08), then the battery has a short circuit and is defective).

## REMOVING AND INSTALLING BATTERY

After putting battery back into vehicle, ensure that the cover is fitted again.

## FAULT FINDING


### BATTERY DISCHARGES

(Leakage current suspected)

**Test conditions:** Battery fully charged, clock disconnected.

#### Note:

Possible faults: corroded and dirty contacts, wires with chafed through insulation, internal short circuit in components.




## FAULT FINDING:

### STARTER TURNS TOO SLOWLY TO START ENGINE

#### Test conditions:

- Engine oil appropriate to the ambient temperature must be used in the winter months.
- V-belt tension OK.



## FAULT FINDING



### STARTER DOES NOT TURN

#### Test conditions:

- The cable terminals on the solenoid and earthing strap between the gearbox and bodywork must be firmly fixed and not oxidized.
- Battery charged.

#### Note:

To connect the test lead to the solenoid detach the battery earthing strap.



**Fig 1 Solenoid**

- 1 - Terminal 30 - from battery
- 2 - Terminal 15a - to coil (not on Diesel engined vehicle)
- 3 - Terminal 50 - from ignition switch
- 4 - Connection for field winding

Continued on next page





Fig. 2 Ignition switch


## REMOVING AND INSTALLING STARTER

### Tightening torque for starter securing screws:

Carburetor and Diesel/Turbo Diesel engines:  
80 Nm

#### Removing (6 cyl. Diesel) up to 11.82

- Detach battery earth.
- Support engine with 10-222 and tension lightly.
- Remove oil filter from below.




- Remove engine mounting - arrow -
- Take off starter together with strut.

#### Installing (6 cyl. Diesel), up to 11.82

- Attach starter to cylinder block.
- Secure starter strut together with engine mounting to cylinder block.
- Secure starter strut.
- Bolt engine mounting to bonded rubber bush.
- Install oil filter.
- Connect wiring to starter.
- Attach battery earth.

#### Removing - from 12.82

- Detach battery earth.



- Open up cable binder - 1 -
- Detach wiring from starter.
- Remove screws - 2 - and take starter off.


#### Installing - from 12.82

##### Note:

Secure wiring with binders - 1 - so that no damage can occur.


## 27 Starter, Current Supply


### REPAIRING STARTER (2.0 litre engine) (Bosch)




27-321

## REPAIRING STARTER (6-cylinder Diesel) (Bosch)







**Fig. 1** Pressing bush in and out of bearing housing




**Fig. 2** Bush, pressing in and out  
Soak bush in hot oil before installing



**Fig. 3** Pressing off stop ring




**Fig. 4** Pressing on stop ring




**Fig. 5** Sealing joints and drillings

- A - Operating lever bolt
- B - Housing/mounting bracket joints
- C - Solenoid bolts
- D - Solenoid/mounting bracket joint
- E - Bearing housing/housing joint
- F - Housing bolts
- G - End plate bolts

## REPAIRING STARTER (4-cylinder Diesel) (Lucas)




27–322




**Fig. 1 Pressing in bush**

Soak bush in hot oil before installing.




**Fig. 2 Pressing out bush**




**Fig. 3 Pressing in bush**

Soak bush in hot oil before installing




**Fig. 4 Removing bush**

- A – Support (normal commercial type, such as Kukko No. 22-1)
- b – Puller (normal commercial type, such as Kukko No. 21/1)



**Fig. 5 Mountings for copper bridge**



**Fig. 6 Adjusting pinion**



- Energize solenoid
- Required clearance between ring gear and stop ring  $a = 0,25$  to  $0,5$  mm. Press the pinion lightly against the commutator side when measuring to take up any play.
- If clearance is not correct, adjust with screw -A-. Lock screw with nut -B- and check adjustment again. Then seal nut with paint.

## FAULT FINDING

### ALTERNATOR WARNING LAMP DOES NOT GO OUT WHEN SPEED INCREASES

#### Test conditions:

Connections on alternator and earth strap between engine and body must be tight and not oxidized.



## FAULT FINDING

### ALTERNATOR WARNING LAMP DOES NOT LIGHT UP WHEN IGNITION IS SWITCHED ON


#### Test conditions:

Vee belt tension OK, battery fully charged.

Connections on alternator and earth strap between engine and body must be tight and not oxidized.


#### Note:

On alternator with flexible mounting, earth strap between alternator and engine must have good electrical contact.




#### Note:

Warning lamp is resistance for exciter current circuit of alternator. 80–90 mA should flow through single connector of D+ wire.



Continued on next page



## FAULT FINDING

### CHECKING ALTERNATOR AND VOLTAGE REGULATOR WITH DIGITAL MULTIMETER V.A.G 1315 A

#### Note:

- Before testing, check Vee belt tension, alternator mountings, wire routing and earth straps.
- Check only with battery fully charged and engine warm.


#### Connecting multimeter

Current supply:

- 1 – red clip to battery plus
- 2 – black clip to battery minus

Test leads:

- 3 – black clip to vehicle earth
- 4 – red clip with test probe on blue D+ wire, near starter  
(in engine compartment up to 11.82)



- Connect multimeter.
- Press button for alternator testing.

Voltage:  
8–12 V

Voltage:  
0 V

Alternator defective.  
(Plus diode short circuit).  
Renew diode plate.

- Start engine
- Speed: 2000–3000 rpm
- Switch large consumer on: high or low headlights, heated rear window, fan

#### Note:

Below the test speed the red LED has no meaning

Green LED comes on

Red LED comes on

Alternator O.K.

Renew voltage regulator – page 27.

Repeat test.

Green LED comes on

Red LED comes on

Alternator O.K.  
Voltage regulator was defective.

Alternator defective. Check parts, and renew as necessary. Install old voltage regulator again.

## REMOVING AND INSTALLING ALTERNATOR (2,0 litre engine)






Fig. 1 Securing alternator to bracket


27-259

## REMOVING AND INSTALLING ALTERNATOR (4-cylinder Diesel)




27-571

## REMOVING AND INSTALLING ALTERNATOR (6-cylinder Diesel) up to 11.82



27-572

## REMOVING AND INSTALLING ALTERNATOR (6-cylinder Diesel, from 12.82)




27-566

## REMOVING AND INSTALLING ALTERNATOR


(6-cylinder Turbodiesel)

### Removing

- Disconnect battery earth.



- Remove bonnet and detach transport bar -arrow-.



- Remove self-locking nut -2- on alternator mounting.
- Lift vehicle and remove screw -1- in tensioning strut.
- Remove upper securing screw.
- Take Vee belt off and take generator out downwards.
- Remove suction cover. Release wire clip and pull connector off.

### Installing


- Attach connector, secure with wire clip and install suction cover.
- Lift alternator into upper mounting and secure with screw (M 8 x 100).
- Put belt on and tension alternator with screw -1- on tensioning strut.
- Lower vehicle, **install new self-locking nut -2-** with washer on securing screw.
- Attach transport bar.
- Lift vehicle, tension belt and secure upper screw on tensioning strut.

### Note:

Belt deflection - approx. 2 mm.

## REPAIRING 45 A AND 65 A ALTERNATORS

(Bosch)




27-567

## 27 Starter, Current Supply

### REPAIRING 45 A AND 65 A ALTERNATORS (2.80 up to 7.80)


(Bosch)



27-568

**REPAIRING 45 A AND 65 A ALTERNATORS (from 8.80)**

(Bosch)



27-569

## REPAIRING 90 A ALTERNATOR (Bosch)

### Voltage regulator/carbon brushes

- Checking – Fig. 2
- with V.A.G 1315 A: page 17

8 Nm

### Bearing (drive end)

- Remove with separating appliance e.g. Kukko 15/1 or 17/1 and puller e.g. Kukko 18/0
- Installing: Press inner race onto stop. Always use new bearing.

### Suppression condenser

### Housing

- Mark position in relation to end plate.

### End plate

- Mark position in relation to housing

### Spacer

- Removing: Use separating appliance, e.g. Kukko 15/0 or 17/0 and puller e.g. Kukko 18/0.

### O ring

- Lubricate with multi-purpose grease

### Diode plate

- Checking – Fig. 16
- Removing – Fig. 8

### Stator

- Checking – Fig. 10, 11
- Removing – Fig. 8

### Fan

- Direction of rotation shown by arrows.

### Belt pulley

- Diameter 61 mm

40 Nm

### Bearing (Slip ring end)

- Removing – Fig. 6
- Installing: Press inner race onto stop. Always use new bearing.

### Rotor

- Checking – Fig. 13, 14
- Removing: Fig. 7

27-556




**Fig. 1** Checking voltage regulator/carbon brushes

Length of carbon brushes:

New: approx. 10 mm

Wear limit: approx. 5 mm. If necessary unsolder connections (arrows) and renew carbon brushes.



**Fig. 2** Checking voltage regulator/carbon brushes (hybrid)


Length of carbon brushes:

new approx. 13 mm


Wear limit approx. 5 mm

**Note:**

Supplied complete as service part and can be installed with alternator in situ.




**Fig. 3** Alternator connector with flat clip




**Fig. 4** Alternator connector with wire clip

If the connector -1- with flat clip is replaced by connector -3- the detent lug for the wire clip -4- must be ground off in order to ensure that clip fits properly.

If an alternator with wire clip is installed in a vehicle with connector -1- the flat clip attachment -2- is to be used.



**Fig. 5** Suppression condenser connection




**Fig. 6** Removing ball bearing

A – Separating appliance  
e.g. Kukko 15/0 or 17/0

B – Puller  
e.g. Kukko 18/0

**Note:**


Do not damage slip ring.



**Fig. 7** Removing rotor – Three arm puller


**Note:**

The three arm puller must grip behind the bearing plate otherwise the screws will either be torn out or sheared.



**Fig. 8** Removing and installing stator/diode plate

To unsolder connections use iron with max. 300 Watts. Use long nosed pliers to dissipate heat. (One connection more on 90 A alternator).



**Fig. 9 Checking stator/earth short**

**Tester: V.A.G 1315 A**

Press button for resistance measurement. Connect leads to the measuring points 1 and 2; 1 and 3; 1 and 4 in turn.

A flashing resistance reading must be indicated in the  $k\Omega$  range.




**Fig. 11 Checking stator/open circuit**

**Tester: V.A.G 1315 A**

Press button for resistance measurement. Connect test leads to winding ends 1 and 2; 1 and 3; 2 and 3 in turn. At each measurement 0 Ohms should be indicated:

If there is a break in circuit a flashing resistance reading must be indicated in the  $k\Omega$  range.




**Fig. 10 Checking stator/earth short on 90 A alternator**

**Tester: V.A.G 1315 A**

Press button for resistance measurement. Connect leads to the measuring points 1 and 2; 1 and 3; 1 and 4; 1 and 5 in turn.

A flashing resistance reading must be indicated in the  $k\Omega$  range.



**Fig. 12 Checking stator/open circuit 90 A alternator**

**Tester: V.A.G 1315 A**

Press button for resistance measurement. Connect test leads to winding ends 1 and 2; 1 and 3; 1 and 4; 2 and 3; 2 and 4; 3 and 4 in turn.

At each measurement 0 Ohms should be indicated.


If there is a break in circuit a flashing resistance reading must be indicated in the  $k\Omega$  range.



**Fig. 13** Checking rotor/earth short

**Tester: V.A.G 1315 A**

Press button for resistance measurement. A flashing resistance value must be indicated in the  $K\Omega$  range.




**Fig. 14** Checking rotor/winding short or open circuit

**Tester: V.A.G 1315 A**

Press button for resistance measurement. Specified readings.

- 35 A-alternator – 3.4–3.75  $\Omega$
- 45 A-alternator – 3.4–3.7  $\Omega$
- 55 A-alternator – 3.4–3.75  $\Omega$
- 65 A-alternator – 2.8–3.0  $\Omega$
- 90 A-alternator – 3.0–4.0  $\Omega$

Open circuit if a flashing resistance value is indicated in the  $K\Omega$  range. Winding short if resistance is below specified reading.




**Fig. 15** Checking diode plate

**Tester: V.A.G 1315 A**

- Unsolder stator windings. Press resistance and voltage measuring buttons simultaneously.
- Checking plus diodes: place black test probe on positive heat sink – 1 – (the same as B+) and the red probe to the collection points – 2 – one after the other.
- Checking minus diodes – place red probe to negative heat sink – 3 – and black probe to collection points – 2 – one after the other.
- Checking **exciter diodes**: Place black probe onto contact rail – 4 – (the same as D+) and red probe to collection points – 2 – one after the other.

The indication for all tests must be 3 times 50–80  $\Omega$ . If this is not the case, renew diode plate.



**Fig. 16** Checking diode plate  
90 A alternator

**Tester: V.A.G 1315 A**

- Unsolder stator windings.
- Press buttons for resistance and voltage test at same time.
- Checking plus diodes: Black clip on plus heat sink –1– (B+) and red clip to collection points –2– and point 5 one after the other.
- Checking minus diodes: Red clip on minus heat sink –3– and black clip to collection points –2– and point 5 one after the other.
- Checking exciter diodes: Black clip on –4– (D+) and red clip to collection points –2– one after the other.

The readings for all tests must be 3 times 50–80 Ohm. If this is not the case, renew the diode plate.

## REPAIRING DASH PANEL INSERT (up to 11.82)

### WITH TACHOGRAPH


Notes on tachograph – page 43

#### Caution:

Disconnect battery earth.

#### Dash panel insert

- Removing:
  - Detach tachograph drive cable
  - Pull knobs off fresh air and heater controls
  - Remove securing screws on left and right
  - Remove switches
  - Pull connectors off dash insert.




#### Coolant temperature gauge

- Checking – Fig. 3
  - up to 7.76 with built-in voltage stabilizer
  - from 8.76 one voltage stabilizer for fuel and coolant temperature gauges – Fig. 4

#### Fuel gauge

- Checking – Fig. 2
  - up to 7.76 with built-in voltage stabilizer
  - from 8.76 one voltage stabilizer for fuel gauge and coolant temperature gauge – Fig. 4



#### Printed circuit

- Check circuits for continuity with an ohmmeter.
- Wiring of connections on multi-pin connector – Fig. 1

#### Note:

Do not install printed circuit from 3.77 (Fig. 8, 9) together with voltage stabilizer from 8.76 to 2.77 (Fig. 5)


- Measuring the stabilized voltage – Fig. 7

90-646

**REPAIRING DASH PANEL INSERT (up to 11.82)****WITH CLOCK AND SPEEDOMETER**


**Note on odometer in speedometer**  
– page 43.

**Caution:**  
Disconnect battery earth.

**Note:**

Do not install printed circuit from 3.77 (Fig. 8, 9) together with voltage stabilizer from 8.76 to 2.77 (Fig. 5).

90–647



**Fig. 1 Wiring of contacts on multi-pin connector**

- 1 - Oil pressure warning lamp from oil pressure switch
- 2 - Turn signal warning lamp, terminal 49a
- 3 - High beam warning lamp, terminal 56a
- 4 - Clock/plus wire, terminal 30
- 5 - Temperature gauge sender
- 6 - Earth, terminal 31
- 7 - Instrument lighting
- 8 - Plus wire, terminal 15
- 9 - Fuel gauge sender
- 10 - Alternator warning lamp, terminal 61




**Fig. 2 Checking fuel gauge**

**Test conditions:** Battery O.K.

- Pull wire from fuel gauge sender off, connect tester V.A.G 1301 to open wire and earth.
- Set following values on potentiometer:  
R : 350  
1/4: 215  
1/1: 60

**Fault finding programme (from 8.76)**

- page 44




**Fig. 3 Checking coolant temperature gauge**

**Test conditions:** Battery O.K.


- Pull wire from coolant temperature sender off, connect tester V.A.G 1301 to open wire and earth.
- Set following values on potentiometer:  
I : 500; II : 60

**Fault finding programme (from 8.76)**

- Page 44




**Fig. 4 Voltage stabilizer (from 8.76)**



**Fig. 5 Voltage stabilizer**

left : from 3.77


right: from 8.76 to 2.77



**Fig. 6 Voltage stabilizer  
(from 8.76 to 2.77)**

A = Cooling surface

To prevent reversal of polarity and damage, the cooling surface must be in contact with the metal cover of the speedometer.




**Fig. 7 Checking voltage stabilizer  
(from 8.76)**

Connections on stabilizer:


Plus input	(+E)
Earth	(⊥)
Plus output	(+A)

**Test conditions:** Battery O.K.


Measure voltage between plus output and earth. It must be approx. 10 V. If the voltage is above 10.5 V or below 9.5 V, the stabilizer is defective.




**Fig. 8 Identification of printed circuit of  
voltage stabilizer from 3.77  
(see Fig. 9 also)**




**Fig. 9** Identification of printed circuit for voltage stabilizer from 3.77 (see Fig. 8 also)




**Fig. 12** Routing of tachograph cable



**Fig. 10** Removing and installing speedometer cable



**Fig. 13** Routing of tachograph cable



**Fig. 11** Removing and installing speedometer cable

## Note:

Route the cables so that they are neither squeezed, kinked or damaged, otherwise indication will be incorrect or cable will break.

Do not grease connection to speedometer. Grease can get into instrument and cause needle to stick.

# REPAIRING DASH INSERT (from 12.82) WITH REV COUNTER AND TACHOGRAPH

Notes on trip recorder – Page 43

## Important:

Detach battery earthing strap

### Printed circuit

- Allocation of connections at multiple connectors – Fig. 1
- Designation of connections on printed circuit – Fig. 2

### Warning lamp housing

- Designation of bulbs – Fig. 3

### Heat sink

- for voltage stabilizer

Bulb 12 V/1.2 W

Common earthing point

Voltage stabilizer  
● checking – Fig. 4

Securing screw  
for tachograph

Securing screw  
for retaining plate

### Rev counter with fuel gauge

- Removing and installing sensor – Fig. 10
- Connections to sensor – Fig. 12
- Checking – Fig. 5
- Checking – Fig. 6

### Dash insert

#### Removing

- Unscrew tachograph cable
- Remove knobs for fresh air and heating
- Remove switch, detach connections
- Unscrew fastening screws on left and right
- Detach dash-insert plug connections

### Tachograph

- Routing cable – Figs. 7, 8, 9
- Route cable so that it cannot be squeezed, kinked or damaged; otherwise incorrect indication or cable will break

90-648

# REPAIRING DASH INSERT (from 12.82) WITH SPEEDOMETER AND REV COUNTER

Notes on odometer in speedometer – Page 43.

Notes on tachograph – Page 43.

## Important

Detach battery earthing strap.

## Voltage stabilizer

- Checking – Fig. 4

Common earthing point

Heat sink

Bulb for instrument lighting and warning lamps 12 V/1.2 W

Rev counter

Speedometer

## Note:

Route cable such that it cannot be squeezed, kinked or damaged: otherwise incorrect indication or cable will break

Coolant temperature gauge

- Checking – Fig. 6

## Dash insert

- Removing
  - Unscrew speedometer cable
  - Remove knobs for fresh air and heating regulation
  - Remove switch, detach connections
  - Unscrew fastening screws on left and right
  - Detach dash-insert plug connections

Instrument panel housing

Headlight switch

Housing for multiple plug connection

## Printed circuit

- Allocation of connections at multiple connectors – Fig. 1
- Designation of connections on printed circuit – Fig. 2

## Fuel gauge

- Removing and installing sensor – Fig. 10
- Connections at sensor – Figs. 11, 12
- Checking – Fig. 5

## Warning-lamp housing

- Designation of bulbs – Fig. 3

Switch for fresh-air blower

Emergency-lights switch

Cover

Symbol panel for warning lamps


Blank cover for switch insert

## Radio (as of 8.84)

- Removing and installing – Fig. 13
- Removing and installing aerial – Fig. 14


Cover for fresh air and heating regulation

90-643



**Fig. 1 Allocation of connections at multiple connector**

- 1 – Warning lamp for oil pressure
- 2 – Indicator lamp for preheating time
- 3 – +, terminal 15
- 4 – Indicator lamp for trailer operation
- 5 – Bulbs for instrument lighting
- 6 – Fuel gauge from sensor
- 7 – Gauge, terminal 30 or rev counter, terminal 1 or terminal W (diesel engine)
- 8 – Coolant temperature indicator from sensor
- 9 – Earth, terminal 31
- 10 – Main-beam indicator lamp
- 11 – Roof-vent indicator lamp
- 12 – Turn-signal indicator lamp
- 13 – Generator warning lamp
- 14 – Indicator lamp for dual brake circuit and handbrake



**Fig. 2 Designation of connections on printed circuit**

#### **Voltage stabilizer**

- 1 – Input, terminal 15
- 2 – Earth
- 3 – Output: approx. 10 V

#### **Rev counter**

- 4 – Earth
- 5 – Terminal 1 (petrol engine)  
Terminal W (diesel engine)
- 6 – Terminal 15

#### **Fuel gauge**


- 7 – to fuel gauge sensor
- 8 – from voltage stabilizer output

#### **Coolant temperature indicator**

- 9 – from voltage stabilizer output
- 10 – Earth
- 11 – to sensor, coolant temperature indicator


#### **Common earthing point**

- 12 – Earth



**Fig. 3 Designation of bulbs in lamp housing**

- 1 – Warning lamp for oil pressure (red)
- 2 – Indicator lamp for dual brake circuit and handbrake (red)
- 3 – Generator warning lamp (red)
- 4 – Turn-signal indicator lamp (green)
- 5 – Indicator lamp for preheating time (yellow)
- 6 – Indicator lamp for trailer operation (green)
- 7 – Roof-vent indicator lamp (green)
- 8 – Main-beam indicator lamp (blue)




**Fig. 4 Checking voltage stabilizer**

- 1 – Input terminal 15
- 2 – Earth
- 3 – + output

**Test condition:** Battery O.K.

Connect voltmeter between + output – 3 – and earth – 2 –. Voltage must be approx. 10 V.

If voltage in excess of 10.5 V or less than 9.5 V, voltage stabilizer is defective.



**Fig. 5 Checking fuel gauge**

**Test condition:** Battery O.K.

- Detach wire from sensor for fuel gauge, connect V.A.G tester 1301 to detached wire and earth.

**Note:**


In the delivery van the fuel gauge sensor is not accessible: remove fuel tank – Workshop Manual, engine booklet.

- Start engine and set following values at potentiometer:

- 350 – needle position R
- 200 – needle position 1/4
- 140 – needle position 1/2
- 50 – needle position 1/1

Permissible deviation: one needle width to right or left.

**Fault finding chart** – Page 44



**Fig. 6** Checking coolant temperature indicator

**Test conditions:** Battery O.K. and relay for coolant level indicator detached.

- Detach wire from sensor for coolant temperature indicator, connect V.A.G 1301 to detached wire and earth.

- Start engine and set following values at potentiometer:

650 – needle position 1, engine cold


300 – needle position 2

70 – needle position 3, engine warm


Permissible deviation: one needle width to right or left.

4 – LED for coolant temperature (too hot, red)/lack of coolant


**Fault finding chart** – Page 44




**Fig. 7** Routing tachograph cable



**Fig. 8** Routing tachograph cable




**Fig. 9** Routing tachograph cable



**Fig. 10 Removing and installing fuel gauge sender**


**Note:**

With delivery van only, remove fuel tank – Workshop Manual, engine booklet.



**Fig. 11 Connections at sender (up to 12.75)**

- 1 – Earth
- 2 – to fuel gauge
- 3 – Fuel hose clip




**Fig. 12 Connections at sender (from 1.76)**

Petrol engine: Connector, 3 pins

- 1 – Earth
- 2 – Positive connection for fuel pump
- 3 – to fuel gauge


Diesel engine: Connector, 2 pins

- 1 – Earth
- 2 – to fuel gauge



**Fig. 13 Removing and installing radio (from 8.84)**

- Disconnect battery earth strap.
- Remove securing bracket - 1 - on reverse side of radio.
- Push wire loop - 2 - through the holes in the front plate until the side retainers are disengaged.
- Pull radio out of dash panel and detach connections.



**Fig. 14 Removing and installing aerial**

- Disconnect battery earthing strap.
- Detach relay plate.
- Remove tapping screw - arrow - from retaining bracket.
- Remove aerial cap nut.
- Pull aerial connection out of radio.
- Pull aerial out from underneath.

#### NOTES ON TACHOGRAPH:

The tachograph drive shaft is sealed at the gearbox, at the differential and on the tachograph itself.

In the Federal Republic of Germany, the system has to be checked and resealed by an authorised person, in accordance with German traffic regulations, after every repair, change to distance/turns and after expiry of the time prescribed by law since the last check.

Outside the Federal Republic of Germany please contact the tachograph manufacturers agents.


#### NOTES ON ODOMETER IN SPEEDOMETER:

In the Federal Republic of Germany, zeroing the odometer is not permitted, and when the speedometer is renewed, the distance travelled thus far has to be entered in the service schedule, and the entry has to be certified with an official stamp and signature.

## FAULT FINDING PROGRAMME:

### CHECKING FUEL AND COOLANT TEMPERATURE GAUGES

Dependent upon the defect, the following results could be obtained when checking the gauges with V.A.G 1301 tester – pages 34, 40, 41 –.




**FAULT FINDING PROGRAMME:****HORN SYSTEM DEFECTIVE****Test conditions:**

- Gap between steering wheel and steering column switch correctly adjusted (up to 9.79) – Fig. 1.
- Horn contact wire underneath horn plate in order.
- S9 fuse in order.
- Ignition switched on.


**Note:**

If the defect is not found using fault finding programme, check earth wire between steering column and steering box – page 67, Fig. 2.



**Fig. 1** Gap between steering wheel and steering column switch (up to 9.79)

a = 2 up to 3 mm







Fig. 2 Contact A 11, connect test wire





Fig. 3 Connect brown/blue wire to earth





Fig. 4 Contact E 11, connect test wire





Fig. 5 Contact A 7, connect test wire

## REPAIRING WINDSCREEN WIPER SYSTEM

### Note:

Apply grease G 000 602 to ball joints at wiper bracket and wiper motor




### Note:

Observe different versions  
– Parts Lists

92 - 368

## REPAIRING WINDSCREEN WASHER SYSTEM,

with electric or foot pump



**Note:**  
Observe different versions  
– Parts Lists

92-369

## 92 Windscreen wiper and washer system

### ADJUSTING WIPER ARM ADJUSTING JET (WINDSCREEN WASHER SYSTEM)

Wiper arm:


a = 120 mm

b = 130 mm

Tighten hexagon nut for securing wiper arms to 12 Nm.

Jet for system with:


Foot pump	Electric pump
c = 50 mm	c = 200 mm
d = 480 mm	d = 480 mm
e = 50 mm	e = 200 mm
f = 540 mm	f = 540 mm



Adjust jet with tool 3125.


### WINDSCREEN WIPER MOTOR — ADJUSTING PARK POSITION

- Allow wiper motor to move to end position.
- Fit crank and align as indicated.



LHD


$\alpha = 0^\circ \pm 8^\circ$



RHD

$\alpha = 0^\circ \pm 8^\circ$


## REPAIRING HEADLIGHT WASHER SYSTEM, up to 11.82



**Note:**  
Observe different versions  
– Parts Lists

92-370

## REPAIRING HEADLIGHT WASHER SYSTEM, from 12.82



**Note:**  
Observe different versions  
- Parts Lists

92-371


## REMOVING AND INSTALLING RUBBER INSERT

- At closed side of rubber insert press both steel rails together using universal pliers, remove laterally from upper clamp and pull rubber insert complete with rails out of remaining wiper-blade clamps.



92-015

- Insert new rubber insert into lower clamps of wiper blade.
- Insert both rails into first groove of rubber insert so that recesses in rails face the rubber insert and engage in rubber lugs of groove.
- Press both steel rails and rubber insert together again using universal pliers and insert into upper clamp so that lugs engage on both sides in retaining grooves (arrow) of rubber insert.



92-016

## ADJUSTING JET (HEADLIGHT WASHER SYSTEM)

Up to 11.82 jet beneath headlight:  
Adjust with tool 3125


a = 20 mm  
b = 15 mm

As of 12.82 jet next to headlights:  
Adjust with tool 3019 A

a = 15 mm  
b = 12 mm

### Note:

Press tool into jet assembly as far as stop and perform appropriate adjustment.  
Do not damage jet.



92 - 373

## REPAIRING STEERING COLUMN SWITCH, up to 9.79

### Note:

- Detach battery earthing strap
- Tightening torque of hexagon nut M 16 × 1.5 for securing steering wheel: 50 Nm

### Turn-signal switch

Service part has contacts for parking light

- Adjusting gap
- shear bolt

### Windscreen wiper switch

- Service part has contacts for head-light washer system, windscreen washer pump and intermittent function

### Locking plate

(up to 10.75)

Remove upwards with pliers

- Peen over slightly when installing

### Housing, upper part

### Mounting for switch with steering lock

Some versions have no locking pin. Do not forget support ring when installing (see 'Running Gear' booklet).

### Ball bearing

Cannot be removed

### Shear bolt

- Removal: To remove steering column switch, drill out with left-hand drill
- Installing: Before shearing bolt head, set gap (2 mm – 3 mm) between steering wheel and upper part of housing

### Lock cylinder

- Removal
- up to 10.75: Opening for removal of lock cylinder is accessible after locking plate has been removed
- from 11.75: – Page 56, Fig. 1

### Ignition/starter switch

- Removal: Remove steering column switch complete

### Housing, lower part

- Pull off towards driver's seat

### Housing, centre part

### Phillips screw

For securing centre part of housing to mounting for switch and steering lock

### Note:

- Observe different versions
- Parts Lists

94-202


# REPAIRING STEERING COLUMN SWITCH, from 10.79

## Note:

- Detach battery earthing strap
- Tightening torque of hexagon nut M 16 x 1.5 for securing steering wheel: 50 Nm
- Distance between steering wheel and turn-signal switch cannot be altered.

## Turn-signal switch

with switch for manual headlight dipping and headlight flasher




## Note:

- Removing and installing steering column switch
- Page 56


Switch for windscreen wipers and wipe/wash facility

Negative contact



## Mounting for switch with steering lock

- Removing lock cylinder
- Page 56, Fig. 2




Ignition/starter switch

- Removal: Remove steering column switch complete

Housing, upper part

Housing, lower part

- Pull off towards driver's seat



## Note:


Observe different versions

- Parts Lists


94-541

## REMOVING AND INSTALLING STEERING COLUMN SWITCH, from 10.79

- Detach battery earthing strap.
- Remove steering column trim.
- Detach connector.
- Lever off horn plate.
- Remove steering wheel.




- Remove screw - arrow -
- Pull turn signal switch and windscreen wiper switch off steering column.



- Disengage windscreen wiper switch - arrow - and pull off from turn signal switch.


## REMOVING LOCK CYLINDER

- Detach battery earthing strap.
- Remove turn signal and windscreen wiper switches.
- Carefully drill (3 mm diam.) the steering column lock switch housing - Figs. 1, 2.



**Fig. 1 Steering column lock housing**  
(11.75 up to 9.79)

a = 13 mm



**Fig. 2 Steering column lock switch housing**  
(from 10.79)

a = 12 mm

b = 7 mm

- Depress lock cylinder retaining spring through the drilling and remove lock cylinder.
- Do not remove locking plate (up to 10.75) to prevent the lug on the turn signal switch from being inadvertently broken off on vehicles without intermittent facility.

## REPAIRING HEADLIGHTS

### Note:

- Adjusting headlights - Fig. 3
- Specified values for headlight adjustment
- "Maintenance" booklet

### Housing

- Removing and installing - Fig. 2
- Removing and installing lens - Fig. 1

### Tab washer

### Support ring

- Removing and installing - Fig. 2

### Hinged support

- Unhook following quarter turn

### H4 halogen lamp

12 V, 60/55 W with retaining spring

### Headlight insert

### Adjusting screw

- Adjusting headlights - Fig. 3

### Protective cap

different for normal bulb and H4 halogen bulb

### Adjusting nut

Ensure correct position in support ring

### Tension spring

### Bulb

12 V, 45/40 W with holder

### Bulb for side lights

12 V, 4 W with lamp socket

### Note:


- Observe different versions
- Parts Lists

94-544



**Fig. 1 Removing headlight trim**

- Disengage headlight trim quickrelease screws - arrow - by turning  $\frac{1}{4}$  turn.
- Remove trim.




**Fig. 3 Adjusting headlight**

Screw - A - for horizontal setting

Screw - B - for vertical setting

**Note:**

See "Maintenance" booklet for setting figures.




**Fig. 2 Removing and installing housing  
Removing and installing carrier ring**

Housing screws - Arrow A

Carrier ring screws - Arrow B

## REPAIRING TAIL LIGHT

Pick-up

**Note:**


Observe different versions  
- Parts Lists

## REPAIRING TAIL LIGHT

Delivery van

**Note:**

Observe different versions  
- Parts Lists




## REPAIRING FOG LAMPS,

Delivery van and Pick-up


### Note:

Settings


— "Maintenance" booklet



## REPAIRING REAR FOG LAMP, Delivery van



## REMOVING AND INSTALLING FUSE BOX/RELAY PLATE (up to 9.79)



97-207

Fig. 1 Front view of fuse box/relay plate

**Attention**

**Always** detach the battery earthing strap when working on the electrical system.

**Fuse positions**


1 - Dipped headlight, left	8 A
2 - Dipped headlight, right	8 A
3 - Main beam, left	8 A
4 - Main beam, right	8 A
5 - Heated rear window	16 A
6 - Brake lights, emergency flasher	8 A
7 - Interior light	8 A
8 - Turn signals	8 A
9 - Reversing light, horn	8 A
10 - Heated rear window control	8 A
11 - Fresh air blower, wiper motor	8 A
12 - Fog lights	8 A
13 - Parking light, right	8 A
14 - Parking light, left	8 A
15 - Electric fuel pump	16 A

**Relays on relay plate**

J - Headlight dimmer/flasher relay
K - Heated rear window relay
L - Vacant
M - Windscreen wiper motor relay
N - Emergency warning light relay

**Note:**

For different fuse layout and installation of further relays, control units and fuses on relay adapters, see the appropriate current flow diagrams.



**Fig. 2 Rear view of fuse box/relay plate**

#### Attention

Always detach battery earthing strap when working on electrical system.


#### Connection layout

- A – Front wiring loom connection (white)
- B – Vacant
- C – Front wiring loom connection (colourless)
- D – Dash panel wiring loom connection (blue)
- E – Dash panel wiring loom connection (black)
- F – Rear wiring loom connection (yellow)
- G – Separate connector
- H – Separate connector (terminal 30)

#### Note:

The designation of the connectors A–H in block capitals and figures are identical with the contact designations in the Current Flow Diagrams and Fault Finding Programmes.

## REMOVING AND INSTALLING RELAY PLATE AND FUSE BOX (as of 10.79)



**Fig. 1** Relay plate and fuse box/front view

### Caution

Disconnect battery earthing strap when working on electrics.

### Fuse assignment


1 – Dipped beam, left	8 A
2 – Dipped beam, right	8 A
3 – Main beam, left	8 A
4 – Main beam, right	8 A
5 – Heated rear window	16 A
6 – Brake light, hazard warning	8 A
7 – Interior light	8 A
8 – Turn signal	8 A
9 – Reversing light, horn	8 A
10 – Fresh-air blower	16 A
11 – Wiper motor	8 A
12 – Fog lamp	8 A
13 – Side light, right	8 A
14 – Side light, left	8 A
15 – Reversing lights, electric fuel pump	25 A

### Relays on relay plate

J	– vacant
K	– Relief relay for X-contact
L	– vacant
M	– Relay for intermittent wipe/wash facility – Bridge for wiper motor from M 19 to M 21 (without intermittent operation)
N	– Hazard warning relay

### Note:

Differing fuse layout and installation of further relays, control units and fuses on relay adapters 5-16 are to be taken from the valid current flow diagrams.



**Fig. 2 Relay plate and fuse box/back view**

**Caution!**

Disconnect battery earthing strap when working on electrics.


**Assignment of plug connections**

- A – Connection for front loom (white)
- B – vacant
- C – Connection for front loom (colourless)
- D – Connection for dash loom (blue)
- E – Connection for dash loom (black)
- F – Connection for rear loom (yellow)
- G – Individual connector
- H – Individual connector (terminal 30)


**Note:**

The designations of the connectors A–H in capital letters and figures are identical with the contact designations in the current flow diagrams and fault finding instructions.

## REMOVING AND INSTALLING WIRING LOOMS




97-2166




**Fig. 1** Designation of connectors in steering column vicinity

- 1 – to ignition/starter switch
- 2 – to windscreen wiper switch
- 3 – to turn signal switch to horn plate
- 4 – to headlight dimmer/flasher switch
- 5 – to brake light switch




**Fig. 2** Earth wire on steering column coupling

If horn does not work, check for good electrical connection.



**Fig. 3** Earthing point on rear longitudinal member, left



**Fig. 4** Earthing point on dash panel insert (from 12.82)


Connection for following earth wires:

- to earthing point near relay plate/fuse box
- to 14-pin connector on dash panel insert
- to the switches in dash panel area
- to fresh air blower/to emergency flasher warning lamp
- to fresh air controls lights
- to brake fluid level warning contact
- to tachograph

## EARTHING STRAP CONNECTION SEQUENCE


- 1 - When dismantling, always detach battery earthing strap at battery negative (-) terminal\* first.
- 2 - When assembling, first ensure a good earth connection between body and gearbox (clean metallic connection, threaded connection tightened). Last of all, attach battery earthing cable to battery negative (-) post.

\* To prevent voltage drop and corrosion damage, the earthing straps must **not** be detached.



- 1 - Battery
- 2 - Gearbox
- 3 - Engine
- 4 - Battery negative (-) post
- 5 - Earthing point - gearbox
- 6 - Earthing points - body - **do not slacken off**

ROUTING WIRES IN VICINITY OF BATTERY



**Note:**


To avoid voltage drop and corrosion, the earthing strap must not be detached at the B-pillar

**Note:**

Detach earthing strap at battery when working on electrics.


97-2157

## ROUTING LAYING WIRES IN VICINITY OF GEARBOX 6 cylinder engine




97-2158

**ROUTING WIRES IN VICINITY OF STARTER**  
6 cylinder turbocharged diesel engine





97-2159

## ROUTING WIRES IN VICINITY OF STARTER 6 cylinder petrol and naturally aspirated diesel engine




97-2160

**ROUTING WIRES IN ENGINE COMPARTMENT**  
6 cylinder naturally aspirated and turbocharged diesel engine




## ROUTING WIRES IN ENGINE COMPARTMENT 6 cylinder petrol engine




97-2165

ROUTING WIRES, REAR WIRING LOOM  
Pick-up



97-2161

## ROUTING WIRES, REAR WIRING LOOM Delivery van



97-2162